

# How to Vote with eSlate

1. Turn SELECT wheel to move through the ballot.
2. Press ENTER to mark your choice when highlighted or heard.
3. Press HELP once for on-screen instructions, twice for a poll worker to come.
4. Press PREV to go back a page, NEXT to go forward a page.
5. Pressing CAST BALLOT means you are completely finished voting. You will know your vote has been recorded when you see a waving American flag.



You may listen to the ballot using headphones with volume control.



You may use jelly switches or your sip n' puff to vote if you can't operate the wheel & buttons.



If your polling place is inaccessible, a poll worker can bring the eSlate to your car.

*Accurate. Easy to use. Accessible.*